

00/02/94 14:00:00




FIG. 1.
(PRIOR ART)

FIG. 2 is an exploded perspective view of the device. It shows the front panel assembly (10, 13, 12, 15, 16) and the internal chassis assembly (11, 17a, 17b, 19, 20, 30). The front panel includes a display (15) and control buttons (12, 16). The chassis assembly includes a fan (20), a power supply (19), and various electronic components (30) connected by cables.

FIG. 2.

002221 6469260





FIG. 3A.

[illegible]




FIG. 4.




FIG. 5.




FIG. 6A.




FIG. 6B.




FIG. 7.




FIG. 8.




FIG. 10.




FIG. 11B.